

OPERATING INSTRUCTIONS
3KW WALL MOUNTED DIMPLEX
COURT HEATERS

TO START THE TIMING SEQUENCE

Press the central button– the last selected time period will be used.

TO ADJUST THE TIME PERIOD

Press and hold the central button until the red LED moves to the desired time then release the button.

Note

During play, the position of the red LED will change to indicate how much time is left.